



M4019 Micrometer for Inductive Tracers

Contents:	Page
Front view	2
Back view	3
1. Power supply	4
2. Digital display	4
2.1 Contrast adjustment of digital display	4
3. Adjustment of bar display	5-8
4. Language setting	9
5. Set-up of measuring task	9
5.1 Nominal value setting	9
5.2 Connection of inductive measuring tracers	9
5.3 Positioning of inductive measuring tracers	9
5.4 Setting of tolerance limits	9
5.5 Adjustment of tracer scale factor of inductive tracers	9
5.6 Adjustment of low-pass filter	10
6. Linking of various column micrometers	10-11
7. Interfaces	12
8. Technical data	12
9. Programming interface	13-15
Attention:	
Note security directions acc. to VDE 0411	16

The column micrometer M4019 displays the measuring value as analogue light bar and as numeric value. The measuring device contains four tracer inputs for inductive tracers +A, -A, +B, -B. In comparison to the predecessor model of the AYE 4000 series, the power consumption was approximately halved.

The light bar display is adjusted to the tolerance limits (UL = +100%, LL = -100%). The centre point of the display corresponds to the centre of the tolerance range (0%). The display scale goes up to a tolerance excess of 50%. A tolerance excess is marked by a change in colour from green to yellow or red. In addition, the classification of the measuring value is made available via 5 optocoupler outputs (+12...24VDC).





1. Power supply

Connect the output cable of the included external 24V mains plug via the 8-pole connector to X8 of M4019 and the power supply to 230VAC, 50/60Hz. Subsequently, a self-test of the unit is carried out. To avoid influence of temperature, the measuring equipment should be switched on ten minutes before the first measuring and calibration.

2. Digital display (selection of possible display options by pressing the key ">")

Measuring value – Absolute measuring value according to the formula ((tracer (+A-A+B-B) * factor) + nominal value

This is the display after starting the unit. After approximately 30 sec. without pressing any key, the programme automatically switches back to this measuring value display from the other display modes. It is not possible to change this display value by pressing the UP (^) or DOWN (v) keys.

The values of the following displays may be changed by pressing the keys UP (^) or DOWN (v).

By pressing the key ">", the settings are power failure-proof.

Nominal value – nominal value, setting range +/-999,999

Master – reference master value

Tracer – direct display of measuring tracer inputs, UP (^) and DOWN (v) keys are ineffective

UL – upper limit (absolute value)

UCL – upper control limited (absolute value)

LCL – lower control limited (absolute value)

LL – lower limit (absolute value)

2.1 Contrast adjustment of digital display

Digital display on „Measuring value“.


Switch to the next level by simultaneously pressing the keys UP (^) and DOWN (v). Select the display „Contrast“ by pressing the key ">" and adjust the desired contrast by pressing the keys UP (^) or DOWN (v).

By pressing the key ">", the inputs are power failure-proof.


3. Adjustment of bar display

Digital display on „Measuring value“.


Switch to the next level by simultaneously pressing the keys UP (^) and DOWN (v). Select the display „Bar“ by pressing the key ">" and adjust the desired mode by pressing the keys UP (^) or DOWN (v):




Mode 000,001 – continuous bar from bottom range end




Mode 000,002 – Green bar from centre of tolerance range (0%) to plus or minus.
When the tolerance limit is exceeded, the display is switched to yellow bar from UL (+100%) to plus or red bar from LL (-100%) to minus.




Mode 000,003 – As (000,002), but always from centre of tolerance range (0%).




Mode 000,004 – continuous point LL/GOOD/UL




Mode 000,011 – As (000,001) but with marks red – LL (-100%) and yellow - UL (+100%).



Mode 000,012 – As (000,002) but with marks red – LL (-100%) and yellow - UL (+100%).



Mode 000,013 – As (000,003) but with marks red - LL (-100%) and yellow - UL (+100%).



Mode 000,014 – As (000,004) but with marks red - LL (-100%) and yellow - UL (+100%).

By pressing the key ">", the inputs are power failure-proof.

4. Language setting

Digital display on „Measuring value“.

Switch to the next level by simultaneously pressing the keys UP (^) and DOWN (v). Select the display „Language“ by pressing the key ">" and adjust the desired value by pressing: 0 = German, 1 = English.

5. Set-up of measuring task

5.1 Nominal value setting

Select the digital display „Nominal value“ by pressing the key ">" and adjust the desired absolute value by pressing the keys UP (^) or DOWN (v).

5.2 Connection of inductive measuring tracers

The inductive tracers are connected to the jacks -A, A, B, -B in accordance with the measuring task. The inductive tracers connected to the jacks A and B work in the positive direction, i.e. when pressing the inductive tracer the measuring value gets higher. The inductive tracer connected to jack -A, -B works in the negative direction.

5.3 Positioning of inductive measuring tracers

Remove the inductive tracers.

Select the digital display „Master“ by pressing the key ">" and adjust the reference master value with the keys UP (^) or DOWN (v). Connect the inductive tracer. Insert the reference master value into the measuring device.

When using one inductive tracer:

Position the inductive tracer so that the reference master value is displayed.

When using two inductive tracers:

Position the first inductive tracer approximately on the nominal value (digital display „Master“). Position the second inductive tracer so that the display shows approximately the reference master value (digital display „Master“).

For fine-tuning, adjust the exact reference master value with the keys UP (^) or DOWN (v) (digital display „Master“).

5.4 Setting of tolerance limits

Select the digital display „UL“ by pressing the key ">" and set the desired absolute value of the upper limit by pressing the keys UP (^) or DOWN (v). Subsequently, make settings for the digital displays (UCL: upper control limit, LCL: lower control limit and LL: lower limit).

5.5 Adjustment of tracer scale factor of inductive tracers (normal value 1,000)

The gain was already adjusted in the factory and only needs to be changed in rare cases (e.g. when using a special measuring tracer). A check of the adjustment, especially in combination with the measuring device, should be carried out in regular intervals, e.g. monthly. For the adjustment of the gain a second reference master is necessary. In case of a deviation, the factor may be corrected:

Digital display on „Measuring value“.

Switch to the next level by simultaneously pressing the keys UP (^) and DOWN (v). Select the display „Factor“ by pressing the key ">" and set the desired value by pressing the keys UP (^) or DOWN (v). Max. setting range +/- 5,000.

By pressing the key ">", the inputs are power failure-proof.

5.6 Adjustment of low-pass filter

Adjusting the low-pass filter has an influence on the attenuation of the measuring value display. The higher the low-pass filter value, the higher the attenuation.

Digital display on „Measuring value“.

Switch to the next level by simultaneously pressing the keys UP (^) and DOWN (v). Select the display „filter“ by pressing the key ">" and set the desired value by pressing the keys UP (^) or DOWN (v). Setting range 0 - +10,000. By pressing the key ">", the inputs are power failure-proof.

6. Linking of various column micrometers

Via the plug X2 at the back, a maximum of 4 column micrometers may be linked with each other. Thereby, one device displays the combined measuring result of the remaining 3 micrometers (cf. connection schematics m4019b2).


Switch to the next level by simultaneously pressing the keys UP (^) and DOWN (v). Select the available functions by pressing the key ">" and adjust the desired value with the keys UP (^) or DOWN (v):

local	-	Operation as single column micrometer
CLIENT	-	Operation as single column micrometer; however, the tracer values of the inductive tracers are sent via AUVBUS to the master column for further linkage.
#1 + #2	-	Operation as master column. The displayed measuring value is calculated of the tracer values of the inductive tracers of Client #1 and Client #2 according to the displayed formula.
#1 - #2	-	Operation as master column. The displayed measuring value is calculated of the tracer values of the inductive tracers of Client #1 and Client #2 according to the displayed formula.
#1 + #2 + #3	-	Operation as master column. The displayed measuring value is calculated of the tracer values of the inductive tracers of Client #1, Client #2 and Client #3 according to the displayed formula.
#1 + #2 - #3	-	Operation as master column. The displayed measuring value is calculated of the tracer values of the inductive tracers of Client #1, Client #2 and Client #3 according to the displayed formula.
#1 - #2 - #3	-	Operation as master column. The displayed measuring value is calculated of the tracer values of the inductive tracers of Client #1, Client #2 and Client #3 according to the displayed formula.

A multiplication or division with a constant can be adjusted on the master column using the factor (cf. 5.5).

Example: $(\#1 + \#2)/2$ is achieved with a factor value of 0.5.

Connection schematics of column linkage



7. Interfaces

- X1 Control Input (OPTION)
 - 1 - Output +12V (max. 0,2A)
 - 2 - GND
 - 3 - Input 1: DELETE (if 1-3 connected)
 - 4 - Input 2: MEASURE (if 1-4 connected)
- X2 ADC (OPTION)
 - 1 - ...4 AUVBUS to connect max. 4 column micrometers
 - 5 - Output 5mV/um
 - 6 - GND
- X3 Control Output (Optocoupler plus-switching)
 - 1 - Input supply voltage +12...24VDC
 - 2 - Output classification LL
 - 3 - Output classification LCL
 - 4 - Output classification GOOD
 - 5 - Output classification UCL
 - 6 - Output classification UL
- X4 Input +A for inductive tracer
- X5 Input -A for inductive tracer
- X6 Input +B for inductive tracer
- X7 Input -B for inductive tracer
 - X4-X7 1 - Generator signal for inductive tracer
 - 2 - GND
 - 3 - Input signal for inductive tracer
 - 4 - not connected
 - 5 - Generator signal for inductive tracer
- X8 Input power supply 24VDC
 - 1 - +24V DC
 - 2 - GND 24V
 - 3 - GND
 - 8 - DAC
- X9 USB-Connector for HOST connection

8. Technical data

Power consumption: approx. 5W

Measurements HxWxD: 255mm x 65mm x 160mm

Weight: approx. 1,3 kg

Protection classification: IP20


Working range: +10 - + 45 degrees Celsius, max. rel. atmospheric humidity 75%.

2 x fixing holes at the back with M4 thread

9. Programming interface


The external programming of the measuring task is done using a computer. The control plan administration software PROCProg is used for creating and administrating the control plans and control tasks. The transfer of the prepared control plan into the column micrometer is done via the USB interface on the device.

Control plan administration software PROCProg: revising control plans




Control plan administration software PROCProg: revision of control tasks

zero value, reference master value



Control plan administration software PROCPROG: revising control tasks

inputs for inductive tracers



Security comments according to VDE 0411

General technical

time for warming up	10 minutes
temperature	0...+40 degrees C
atmospheric humidity	up to 75% rel.
frequency	50/60 Hz
power supply voltage	230V +10%, -15%
security	according to VDE 0411, protection class 1

This unit is built and checked under DIN 57411 part 1/VDE 0411 part 1 and left the factory in a safe and perfect condition. To preserve this condition and to guarantee a safe working the user has to follow the comments and warnings which are given in these instructions.

Before turning on the power, you have to make sure that the voltage of operation and the mains voltage correspond. The mains plug may only be inserted into a socket with ground contact. The safety effect may not be abolished by an extension lead without ground connection.

The opening of covers or removing of components, except if it is possible to do by hand, might uncover parts or connections under dangerous voltage. Racks may only be used inside a cover. If an adjustment, a maintenance or a repair at the opened unit under voltage is unavoidable, it may be done only by a qualified employee, who is well acquainted with the dangers involved.

ATTENTION:

After the end of those works, the unit has to be checked according to VDE 0411, part 1.

You have to make sure, that only fuses of the given type and values are taken for replacement. The use of mended fuses or short-circuiting them is inadmissible. If it is presumed, that a safe work is not possible, you have to take this unit out of work. A safe work may not be possible, if

- there are visible damages at the unit.
- the unit does not work.
- after longer storage under unfavourable circumstances.
- after heavy stress of transport.